

MAGICSTONE



Direct light/real time performance

As easy to fill as a pipe,
and easier to maintain

Hand carved,
beautifully balanced in hand

Natural, combustion-free,
thermal design

Personalized with
engraving and gold inlay

Simple, intuitive control
over strength of hit



CONGRATULATIONS ON YOUR NEW ODYSSEY!

It was handcrafted for you by our talented artisans here in Vermont. And while there are lots of tutes and tips at magicstone.us, we want to get you up and running quickly with this amazing instrument.

All You Need for a Great Hit

A Clean Basket • The Right Flame*

*A full size BIC® or a refillable Clipper® lighter
Never use a torch - it will damage your Odyssey.

Limited Lifetime Warranty

This certifies that your MagicStone™ stone vaporizer is warranted to be free from defects in material and craftsmanship under normal use and service for the lifetime of the original consumer. This product, including any attached part or parts, which, upon examination by the manufacturer, are found to be defective will be repaired or replaced with a comparable product or part. More details at magicstone.us

Questions about MagicStone • Warranty or Replacement Service

MagicStone™
823 Campbell Rd.
Bethel, VT 05032
Phone 802-234-5809

Customer Service Hours:
9:30 a.m. – 4:30 p.m. EST
Monday thru Friday excluding Holidays
Email: info@magicstone.us


MAGICSTONE



Handcrafted Smokeless Instruments



GET TO KNOW YOUR INSTRUMENT



Simple Technique

- Remove the magnetic cover by lifting up.
- Fill the basket with flower, break it up but don't grind it or pack it.
- Replace the cover, it will click in place magnetically.
- Place the flame above the firehole and draw easily, as with a pipe.
- Remove the flame when you feel the warmth, 3-4 seconds average.
- Continue drawing for another 3 or 4 seconds.
- Stir the basket after every other hit or so to release more compounds.

It Really Is Your Instrument

Once you've dialed in your balance between how long you light and how hard you draw, varying between light hits and heavy hits will be simple. Just keep a clean basket for consistent performance.



Quick Tips

- Start out drawing slow and easy to learn how to warm the stone chamber.
- After you stop lighting, the longer you draw, the stronger the hit.
- Vary how long you light and how strong you draw for a micro or macro hit.
- Slide your thumb onto the edge of the basket while moving the cover on & off.
- If you're not getting a good hit, clean your basket and/or fill your lighter.
- How often to clean your basket depends on the stickiness of your flower.

DON'T

- Stick anything in the firehole. It will damage your Odyssey.
- Use a torch lighter. It won't work, and will damage your Odyssey.
- Put anything other than dried flower in the basket.
- Put your MagicStone in a dishwasher.